

Play it safe! Flow monitors with ATEX and SIL certification







FS10 | FS20 | FS10-EX | FS20-EX | FS10-dbEX | FS20-dbEX



Play it safe!

Flow monitors with ATEX and SIL certification

FS10 | FS20 | FS10-EX | FS20-EX | FS10-dbEX | FS20-dbEX

	 ATEX zone 1	 ATEX zone 2	 ATEX zones 21 and 22	 SIL 3 with redundancy	 SIL 2 low demand mode	 SIL 1 high and low demand mode
FS10				✓	✓	✓
FS20				✓	✓	✓
FS10-EX		✓	✓	✓	✓	✓
FS20-EX		✓	✓	✓	✓	✓
FS10-dbEX	✓	✓	✓	✓	✓	✓
FS20-dbEX	✓	✓	✓	✓	✓	✓



FlowVision GmbH
Im Erlet 6
90518 Altdorf

Telefon +49 9187 92293-0
Telefax +49 9187 92293-29

info@flowvision-gmbh.de
www.flowvision-gmbh.de